



\*充电电流设置:  $HN4071\ ICH=1800/RSET$

\*R4可向上微调截止电压.公式: $HM4071\ VBAT=4.2V+0.0000304*R4$

\*R4取0欧则默认电压4.2V

Title			
Size	Number		Revision
A4			
Date:	14-Nov-2016		Sheet of
File:	E:\张春峰\做DEMO\DEMO.ddb		Drawn By: