



*输出电压设置: $V_{OUT} = 1V * (R1/R2 + 1)$

*关于EN脚: 只贴EN1->EN脚拉高芯片升压工作; 只贴EN2->EN脚拉低芯片停振, 输入经电感二极管到输出。EN1/EN2二选一

Title		
Size A4	Number	Revision
Date:	4-Jan-2021	Sheet of
File:	E:张春峰做DEMO\DEMO.ddb	Drawn By: