



$I_{OUT} = 0.112V / R_{sen}$   
 $V_{OUT} = 1.18V * (R1/R2 + 1)$   
 $V_{OVP} = 1.18V * (R3/R4 + 1)$   
 \*通常OVP电压设置得比输出电压高，比如5V输出可把过压设置在6V

Title			
Size	Number		Revision
A4			
Date:	8-Dec-2015		Sheet of
File:	E:\张春峰\做DEMO\DEMO.ddb		Drawn By: